

# **AmberGlasses:**

**a standalone  
modularized light-  
weighted BCI device**

---

Ching-Chih Amber Tsao



Traditional steady state visually evoked potentials (SSVEP) paradigms, which require users to gaze at a visual stimulus with both eyes, restricts its applicability in real-world scenarios.

---




**Minimize Visual  
Interference**

**+**




**Ensure Signal  
Quality**



**Amber  
Glasses**

# Design




AG is a 3D-printed EEG-based BCI device that features a **portable, standalone, and monocle** design.

- 1 Transparent Display
- 2 EEG Dry Electrodes (Forehead)
- 3 EEG Electrode Holder
- 4 Rotatable Strap Holder
- 5 EEG Expansion Module

# Digital Fabrication

The prototype is 3D-printed using a FDM printer.



# Specifications

- Dimension:** 25 x 16 x 4 cm
- Visual Stimulation Range:** 0-20Hz
- Wireless Connection:** WiFi 2.4GHz
- Battery:** Lithium Polymer battery 300mAh
- Charging Interface:** USB Type-C



	EEG Channels	Weight
Transparent Display Module	Fp1, Fp2	50g
Sensing Headset	O1, Oz, O2	30g (w/o electrodes)
EEG Expansion Module	Flexible adjustment from Frontal to Parietal	10g (w/o electrodes)

# EEG Expansion Module

Amber Glasses, consisting of a sensing headset, a display module, and an EEG expansion module, is designed to accommodate a wide range of use cases that require mobile EEG capabilities.



Rotation Joint at 0°

The expansion module covers 3 additional channels spanning from the **frontal lobe** to the **parietal lobe** by a rotating joint.




Rotation Joint at 90°

# Display Module

The module is developed on an ESP32 board and equipped with a transparent screen, supporting type-c charging and wireless network connection.

The user can start the stimulation function themselves by touching the capacitive touch sensor during operation.



The transparent screen can provide a **0-20Hz** visual stimulation display or be used as a basic operating interface without blocking the user's line of sight.

# EEG Data Extraction


Bandpass Filter



Select Data  
(channel, event)



Fast Fourier  
Transform





# Use Case - Person Identification



>> **SSVEP Signal** >> **Classification**




**Authenticated / Rejected**

- How do we verify signal quality?
- How do we model personal features?


# SSVEP Signal

Both the fundamental frequency (8 Hz) and the second harmonic (16 Hz) peak were observed during the stimulation state.




# Data Flow and Communication

The device provides a WiFi wireless networking function, which can transmit data to the computer for computation through the wireless network connection and send the computation results back to the device.



# Person Identification Goal

Capture individual differences through EEG (SSVEP) signals



# Machine Learning Classification Result

We tested ML on personal identification using an existing dataset (Y. Sun et al., 2024).

- Decision tree model (DT): FPR **1.73%**, FNR **16.15%**
- Random forest model (RF ): FPR **1.28%**, FNR **13.85%**

		Predicted	
		Non-subject	Subject
Actual	Non-subject	1533	27
	Subject	21	109

		Predicted	
		Non-subject	Subject
Actual	Non-subject	1540	20
	Subject	18	112

$$\text{FPR} = \frac{\text{Logged in}}{\text{Non-subject}}$$

$$\text{FNR} = \frac{\text{Rejected}}{\text{Registered subject}}$$